

ROAD WIDENING/WATER & SEWER CHECKLIST



NOTE: This checklist contains approximate timeframes. Depending on the location and complexity of your project, timelines may be shorter or longer. Please work with Newfoundland Power to determine timelines specific to your project.

In order to avoid delays and receive the best service possible, please use the following checklist to ensure work is completed safely around energized power lines and utility infrastructure.



- In the planning phase, contact Newfoundland Power to set up a Technical Work Request (TWR). A Newfoundland Power Technologist will contact you when your TWR set up is complete.



- Determine if work is taking place in a BellAliant or Newfoundland Power-owned pole area. We will send requests for work in BellAliant-owned pole areas directly to them for, review, design and approval.
NOTE: invoicing of any related utility costs will be issued by the owner(s) of the infrastructure i.e. Newfoundland Power, BellAliant and/or other communication utilities.



- Does your project require the need for a pole/anchor to be held or braced?
NOTE: required when digging within 5ft of a pole or anchor with a 2:1 slope.



- Does your project require the need for relocation of power lines?
NOTE: if new easements are required to relocate power lines, there may be delays.



- Provide AutoCAD drawing of your work to your Newfoundland Power Technologist.



- Provide a timeframe of your job to your Newfoundland Power Technologist.



- Contact Newfoundland Power for Underground Locates and Overhead Clearance Permits.
NOTE: Occupational Health and Safety Regulation requires permits when working within 18ft of overhead or underground power lines.



- Issue Underground Locates and/or Overhead Clearance Permits. **(1-3 weeks)**
NOTE: client signature is needed before work can begin within 18ft of energized power lines.

Does power need to be shut-off in order to complete your project?



- Contact Newfoundland Power to discuss if de-energizing overhead or underground power lines will be required to complete your project?

NOTE: power must be shut-off when working within 10ft of energized power lines.



- If power must be shut-off, we will complete a switching order to isolate your work area.



- Issue Worker Protection Permit.

NOTE: client signature is needed to invoke Worker Protection Permit before work can begin AND client signature is needed to release the Worker Protection Permit when work has stopped.



- Restore power to the work area.



CONTACT US:

Construction Services

Phone: 737-5408 (St. John's) or 1-888-491-5066

Email: constructionservices@newfoundlandpower.com

Visit: [Contractors and Developers Web Page](#)



**Photos
WILL NOT
be accepted
in lieu of
Newfoundland
Power
inspections.**

**Don't
FORGET**

While we are committed to providing you with the best service possible, there may be delays caused by issues outside of our control, such as weather, electricity system maintenance, impact on third party services, etc.

In case of emergencies call 737-5711 or 1-800-474-5711.

CHECKLIST

WHENEVER. WHEREVER.
We'll be there.

NEWFOUNDLAND
POWER
A FORTIS COMPANY